

## Screen Quest™ Live Cell Somatostatin receptor 1 (SSTR1) cAMP Assay Service Pack

Catalog number: 38214  
Unit size: 100 Tests

Component	Storage	Amount (Cat No. 38214)
Component A: Ga16 DNA	Freeze (< -15 °C), Minimize light exposure	1 vial (15 µg)
Component B: Transfectamine™ 5000	Freeze (< -15 °C), Minimize light exposure	1 vial (75 µL)
Component C: Calbryte™ 520 NW	Freeze (< -15 °C), Minimize light exposure	1 vial
Component D: 10X Pluronic® F127 Plus	Freeze (< -15 °C), Minimize light exposure	1 bottle (1 mL)
Component E: HHBS	Freeze (< -15 °C), Minimize light exposure	1 bottle (9 mL)
Component F: DMSO	Refrigerated (2-8 °C)	1 vial (100 µL)
Component G: SSTR1 DNA	Freeze (< -15 °C), Minimize light exposure	1 vial (15 µg)

### OVERVIEW

Somatostatin receptor 1 (SSTR1), a key GPCR, plays an essential role in regulating endocrine and nervous system functions by inhibiting adenylyl cyclase activity and decreasing intracellular cAMP levels. Dysregulated SSTR1 signaling is associated with various conditions, including neuroendocrine tumors, pituitary adenomas, and hormone-related disorders. Traditional methods for studying GPCRs often fail to fully capture the intricate signaling mechanisms of receptors like SSTR1.

The Screen Quest™ Live Cell Somatostatin Receptor 1 (SSTR1) cAMP Assay Service Pack is designed for real-time, high-throughput monitoring of intracellular cAMP changes associated with SSTR1 activation using transfected cell lines and Calbryte™ 520 wash-free calcium fluorescence detection methods. Unlike conventional assays that require cell lysis, this assay maintains cellular integrity, providing both temporal and spatial resolution of SSTR1-mediated signaling events. The assay uses cell lines engineered to express SSTR1 alongside a promiscuous G-protein Ga16. This co-expression enables SSTR1, which typically signals via inhibition of adenylyl cyclase, to couple to Gq signaling, leading to intracellular calcium mobilization. Activation of SSTR1 by specific ligands, such as somatostatin or its analogs, can be detected using calcium-sensitive dyes like Calbryte™ 520 AM, Cal-520™ AM, Fluo-8™ AM, Fluo-4™ AM, or other compatible no-wash calcium kits.

This service pack includes all components required for precise measurement of SSTR1-mediated cAMP changes using FLIPR, FDSS, or equivalent fluorescence microplate readers. It offers researchers a reliable tool to investigate SSTR1 signaling pathways and assess therapeutic compounds targeting this receptor, particularly in endocrine and neuroendocrine research.

### AT A GLANCE

#### Protocol summary

1. Prepare cells for transfection
2. Prepare Transfectamine™ 5000-DNA mixture
3. Add Transfectamine™ 5000-DNA mixture to the cell culture, incubate overnight
4. Transfer the transfected cells to a 96-well plate 24-30 hours after transfection, and incubate the culture overnight
5. Add Calbryte™ 520 NW dye-loading solution
6. Incubate at room temperature or 37 °C for 30-60 minutes

7. Monitor the fluorescence intensity at Ex/Em = 490/525 nm

#### Important Note

Thaw the kit components at room temperature before starting the experiment.

### KEY PARAMETERS

#### Fluorescence microplate reader

Cutoff	515 nm
Emission	525 nm
Excitation	490 nm
Recommended plate	Black wall/Clear bottom
Instrument	Bottom read mode/Programmable liquid handling

**Note:** This kit is compatible with the following instruments: FDSS, FLIPR, ViewLux, NOVOStar, Array Scan, FlexStation, and IN Cell Analyzer.

### CELL PREPARATION

1. Seed the cells such that they will be ~60-70% confluent at the time of transfection.
2. Replace with fresh growth medium before transfection. For example, replace with 2 mL of medium per well for 6-well plates and 6 mL of medium for 10 cm plates.

### PREPARATION OF STOCK SOLUTIONS

#### Calbryte™ 520NW stock solution

1. Add 20 µL of DMSO (Component F) into the vial of Calbryte™ 520NW (Component C), and mix them well.

**Note:** 20 µL of Calbryte™ 520NW stock solution is enough for one plate. Unused Calbryte™ 520NW stock solution can be aliquoted and stored at  $\leq -20$  °C for more than one month, provided the tubes are tightly sealed. Protect from light and avoid repeated freeze-thaw cycles.

### PREPARATION OF WORKING SOLUTION

#### 1X Assay Buffer

1. Combine 9 mL of HHBS (Component E) with 1 mL of 10X Pluronic® F127 Plus (Component D), and mix thoroughly.

## Calbryte™ 520NW Working Solution

1. Add 20  $\mu$ L of Calbryte™ 520 NW stock solution to 10 mL of 1X Assay Buffer, and mix well.

**Note:** The working solution is stable for at least 2 hours at room temperature.

## Transfectamine™ 5000-DNA Mixture

1. Add 15  $\mu$ L of ddH<sub>2</sub>O to the vial of Ga16 DNA (Component A) and SSTR1 DNA (Component G), to get the final concentration of 1  $\mu$ g/  $\mu$ L for both DNAs.
2. Mix 3  $\mu$ g of DNA [for example, 1.5  $\mu$ g of Ga16 DNA (Component A) and 1.5  $\mu$ g of SSTR1 DNA (Component G)] with 200  $\mu$ L of serum-free medium.
3. Add 9  $\mu$ L of Transfectamine™ 5000 (Component B) to the mixture from Step 2.
4. Mix well and incubate at room temperature for 20 minutes.

**Note:** The ratio of Transfectamine™ 5000 and DNA need to be optimized for different cell lines. In general, the ratio for Transfectamine™ 5000 Transfection Reagent ( $\mu$ L) to DNA ( $\mu$ g) should be 3-5  $\mu$ L : 1  $\mu$ g.

**Table 1.** Sample protocols for a 6-well plate and a 10 cm plate

Component	6 well plate (per well)	10 cm plate
Fresh culture medium	2 mL	6 mL
Plasmid	~3 $\mu$ g	10~15 $\mu$ g
Serum-free medium	200 $\mu$ L	600 $\mu$ L
Transfectamine™ 5000 Transfection Reagent	~9 $\mu$ L	~30-45 $\mu$ L

## SAMPLE EXPERIMENTAL PROTOCOL

### Transfection protocol

1. Add Transfectamine™ 5000 -DNA mixture to the culture plate and incubate overnight.
2. Transfer the transfected cells to a 96-well plate 24-30 hours post transfection and incubate overnight.
  - For **adherent cells:** Plate cells overnight in the growth medium at 40,000 to 80,000 cells/well/100  $\mu$ L for a 96-well plate.
  - For **non-adherent cells:** Centrifuge the cells from the culture medium and then suspend the cell pellet in cell growth medium or HHBS at 125,000 to 250,000 cells/well/100  $\mu$ L for a 96-well poly-D lysine plate. Centrifuge the plate at 800 rpm for 2 minutes with brake off prior to the experiments.

**Note:** Each cell line should be evaluated on the individual basis to determine the optimal cell density for the intracellular calcium mobilization.

## Calcium assay


1. Add 100  $\mu$ L/well (96-well plate) of Calbryte™ 520NW working solution into the cell plate.
2. Incubate the dye-loaded plate in a cell incubator for 30 minutes, and then incubate the plate at room temperature for another 15-30 minutes.

**Note:** If the assay requires 37 °C, perform the experiment immediately without further room temperature incubation.

**Note:** If the cells can function well at room temperature for longer time, incubate the cell plate at room temperature for 1 hour (It is recommended that the incubation time be no longer than 2 hours.)

3. Prepare the compound plate with HHBS or your desired buffer.
4. Run the calcium flux assay by monitoring the fluorescence intensity at Ex/Em = 490/525 nm.

## EXAMPLE DATA ANALYSIS AND FIGURES



**Figure 1.** Screen Quest™ Live Cell Somatostatin receptor 1 (SSTR1) cAMP assay principle

## DISCLAIMER

AAT Bioquest provides high-quality reagents and materials for research use only. For proper handling of potentially hazardous chemicals, please consult the Safety Data Sheet (SDS) provided for the product. Chemical analysis and/or reverse engineering of any kit or its components is strictly prohibited without written permission from AAT Bioquest. Please call 408-733-1055 or email info@aatbio.com if you have any questions.